

WX工具选择

WX工具配置概览



工具	WX 1 T005 34 176 11N 200 W	WX 2 T005 34 206 11 200 W	WXD 2 T005 34 266 99N 200 W	WXA 2 T005 34 256 11 200 W	WXR 3 T005 35 005 99N 600 W
 单通道焊台主机	✓	✓	✓	✓	✓
 双通道焊台主机	✓	✓	✓	✓	✓
 双通道拆焊台主机	✓	✓	✓	✓	✓
 双通道热风/焊台主机	✓	✓	✓	✓	✓
 三通道综合返修工作站主机	✓	✓	✓	✓	✓
WXP 65 65 W焊笔 T005 29 212 99 (套件)	✓	✓	✓	✓	✓
WXP 80 80 W焊笔 T005 29 209 99N (套件)	✓	✓	✓	✓	✓
WXP 90 90 W焊笔 T005 29 222 99 (套件)	✓	✓	✓	✓	✓
WXP 120 120 W焊笔 T005 29 202 99 (套件)	✓	✓	✓	✓	✓
WXP 200 200 W焊笔 T005 29 206 99 (套件)	✓	✓	✓	✓	✓
WXMP 40 W (55 W, 带RT 11) 微型焊笔 T005 29 204 99 (套件)	✓	✓	✓	✓	✓
WXMT 2 x 40 W微型脱焊镊子 T005 13 178 99 (套件)	✓	✓	✓	✓	✓
WXDP 120 120 W吸锡枪 T005 13 202 99 (套件)			✓		✓
WXDV 120 120 W吸锡枪 T005 13 205 99 (套件)			✓		✓
WXHAP 200 200 W吸锡枪 T005 27 120 99 (套件)				✓	✓
WRK 热风回流罩套装 T005 15 155 99					✓
WVP 真空拾取装置 T005 29 184 99					✓
WHP 1000 1000 W预热板 T005 33 648 99	✓	✓	✓	✓	✓
WHP 3000 600 W红外线预热板 T005 33 386 99	✓	✓	✓	✓	✓
WHP 3000 1200 W红外线预热板 T005 33 646 99	✓	✓	✓	✓	✓
WXHP 120 120 W预热板 T005 27 029 99	✓	✓	✓	✓	✓
WXSB 200 200 W锡炉 T005 27 043 99	✓	✓	✓	✓	✓
Zero-Smog 4V 最多用于4个工位的移动吸烟仪 T005 36 606 99	✓	✓	✓	✓	✓
Zero-Smog 6V 最多用于6个工位的移动吸烟仪 T005 36 666 99	✓	✓	✓	✓	✓
Zero-Smog 20T 最多用于20个工位的笔式吸烟仪 移动排烟装置 T005 36 706 99	✓	✓	✓	✓	✓
Zero-Smog TL 最多用于2个工位的吸烟仪 T9 10 136 99	✓	✓	✓	✓	✓